



QuickTrick ATV/UTV

Components

Cambers 20-26" 2

Toe Bars 34" 2

QT Pins w/Extender Kit 6

Pin Caps 6

QT Tape Measures 2

QT Back up Bungee 2

**QT Gauge Only When
Purchased Separately* 1

**QT Case Only When Purchased
Separately* 1

Prior to Start

Unpack your QuickTrick system and verify all components are present.

- Please empty all case pockets prior to checking parts
- Test your QuickTrick gauge to ensure a repeatable measurement
- Remember the gauge is accurate to within 1/10 degree which makes it

very sensitive

- If you believe you are not getting repeatable measurements, please go through the steps to recalibrate found at the video link below:
 - http://www.youtube.com/embed/jLHIp_wKdQE
- Make sure your vehicle is on a hard surface
- Attach Pins to toe bars (Pins with 3/8" bolt and washer) by sliding the bolt and washer on the smaller hole to the right and left of center, insert pin through larger hole on other side of toe bar and screw on inserted 3/8" bolt. **Extender pin kit for additional clearance from tire if needed.
- Attach 2 remaining Pins to Verticals by screwing onto the knob/bolt in the correct hole or slider depending on your system.
- Apply pressure to make sure your suspension settles
 - If you prefer...Inexpensive toe plates (floor tiles or 12x12" scrap metal with motor oil or salt in between)

Now you are ready to check your alignment