



QuickTrick ATV/UTV/Side By Side

Components

Verticals 8-15"	2
Verticals 15-20"	2
Verticals 20-26"	2
Toe Bars 26"	2
Toe Bars 34"	2
QT Pins w/Extender Kit	6
Bungee Straps	4
QT Gauge	1
QT Case	1
QT Tape Measures	2

Prior to Start

Unpack your QuickTrick system and verify all components are present.

- Please empty all case pockets prior to checking parts.
- Test your QuickTrick gauge to ensure a repeatable measurement.
 - Remember the gauge is accurate to within 1/10 degree which makes it very sensitive.
 - If you believe you are not getting repeatable measurements, please go through the steps to recalibrate found at the video link below:
 - http://www.youtube.com/embed/jLHIp_wKdQE
- Attach Pins to toe bars (Pins with 3/8" bolt and washer) by sliding the bolt and washer on the smaller hole to the right and left of center, insert pin through larger hole on other side of toe bar and screw on inserted 3/8" bolt.
- Attach 2 remaining Pins to Verticals by removing top nut and screwing onto the knob/bolt in the correct hole or slider depending on your system.
- Attach QuickTrick frames to rims and use backup bungees if needed for grip
- Apply pressure on the bumper a few times to make sure your suspension settles.
- Zero out gauge in front of tire you are taking measurement from prior to placing on bracket.
- Ensure Toe bar is level and vertical is at 90 degrees.
- Make sure your vehicle is on a hard surface.

Now you are ready to check your alignment.