



Proudly Made in the USA

Enclosed:

Two turn plates

2 Magnetic Decals

Instruction sheet

1. Begin by Placing the turn plates in front each wheel
2. Push or drive on
 - a. At $\frac{5}{16}$ of an inch you should have no problem rolling on
 - b. The bottom plate does not have to be square with the wheel because you will mark 0 on the disc **but** wheels should be straight.
3. Place Your Magnetic Decals in preferred position
 - a. Magnets must be $\frac{5}{16}$ " from disk for accurate measurement



1.

4. Use a dry erase marker or scotch blue tape

- a. Mark the 0 position to the 0 on the base plate,
- b. Once you're finished simply wipe the dry erase off or remove tape

No pins to reset, or pointer to get smashed. That's it!

We wanted our plates to be extremely user friendly and our hopes are that we have accomplished that with what we have created.

info@quicktrickalignment.com

205-475-2419

Direct all calls and email to Manufacturer for technical assistance and/or damage