



Components & Instructions

UPC: 00850017571983

13-18" Wheels up to 30" Tires

15-20" Wheels up to 38" Tires

17-22" Wheels up to 38" Tires

QUICKTRICK 4th GEN Slider Toe Kit

COMPONENTS

- | | |
|------------------------------|---|
| • VERTICALS | 2 |
| • TOE BARS | 2 |
| • QUICKTRICK TAPE MEASURES | 2 |
| • QUICKTRICK BACKUP BUNGEEES | 2 |
| • ATTACHMENT PINS W/CAPS | 6 |
| • INSTRUCTIONS | 1 |





Housekeeping Prior to Start

Unpack your QuickTrick system and verify all components are present.

- Make sure your vehicle is on a hard surface
- Apply pressure on the bumper a few times to make sure your suspension settles
 - If you prefer...Inexpensive toe plates (floor tiles or 12x12" scrap metal with motor oil or salt in between)

Now you are ready to check your alignment

- Determine your contacts (Pins, Rec caps on Pins)
 - Pins are used universally between the wheel and tire (Use masking tape or some protection for custom wheels to avoid pin scratches)
 - Red capped spacers are used for wheels with a lip
- Holding the upper part of the bar in place while pressing down on the adjusting knob and contacts should set the bar in place. If you are using the outside of the wheel and pins place as shown below



- Use QuickTrick Backup Bungees if needed
- Do the same for the opposite side and you're ready to measure
- Stretch tape measures from one side of vehicle under the carriage to the other side.
 - Slide tape measure end into slots on toe bar on opposite side of vehicle - Ensure no slack
- Read the tapes carefully. Typically you will have readings something like this:
Front measurement $75 \frac{1}{4}$ - Rear measurement $75 \frac{1}{8}$. This indicates that you have $\frac{1}{8}$ of an inch of toe out. Easy way to remember this is if the front number is higher, you have toe out. If the rear number is higher then of course you have toe in.

Please reach out if you have any questions

Office: 205-475-2419

Email: info@quicktrickalignment.com